

For Assy:  
7697  
Rev: 1/26/2006


# Radio Systems Part# 7697 4 Source Expander Card

### Description

This optional circuit card installs internally in RS-Series consoles and may be wired to switch up to 4 stereo external sources to any console input or route up to 4 stereo feeds from any output.

### Installation

Use the 4 plastic pins to install the circuit board in any free slot on the console inside wall. Install the switch board on the console lid by first carefully cutting the overlay material with a sharp Exacto blade. Use the hardware supplied to mount the switch board. Route the 4 conductor control cable and secure with wire ties to the harness already in place, and plug it into the six terminal connections on both boards. Supply DC to circuit board via the three wire cable from the auxiliary power supply connector (J15) on any six mixer input board.



Option Board Grid	
Manufactured Date:	1988-1998
Status:	Obsolete
Application:	RS-Series
Notes:	



601 Heron Drive · Logan Township, NJ 08085  
856/467-8000 · 856/467-3044 Fax · sales@radiosystems.com  
www.radiosystems.com · www.studiohub.com