

For Assy:
10795
Rev: 1/26/2006

Radio Systems Part# 10795 Super Clock Operation

CLOCK CONTROL

Press start and stop together and hold to enter the clock set mode. Auto and clock lamps will illuminate and the display will reset to 0:00:00.

Press and hold the stop button to advance the hours display.


Press and hold the reset button to advance the minutes display.

Press the start button to exit the set mode and start the clock, or, the clock may be remotely started via a closure to remote control pin 18.

Clock Display



Console Controls (Lower Right Hand)



TIMER CONTROL

Press the start button to begin up timing.

Press the stop button to stop and hold timer display

Press the reset button to return the timer display to 00:00:00

Press the auto button to allow auto start of timer and clock functions. The auto lamp will illuminate

Information Grid	
Manufactured Date:	1995-1997
Status:	Obsolete
Application:	RS-Series Consoles
Notes:	



601 Heron Drive · Logan Township, NJ 08085
856/467-8000 · 856/467-3044 Fax · sales@radiosystems.com
www.radiosystems.com · www.studiohub.com