

Technical Bulletin
No: 201 – Servo Motor Packing

Model: RS-2000, RS-2001, RS-2003 **No:** 201
& RS-2004

Subject: RS-2000 DC Servo Motor **Date:** 07/01/93

In order to prevent damage to new bearings during shipping and handling, your motor(s) have been returned to you with the bottom chrome cover not fully installed. Many of you will recall that the older AC motors have the rotors exposed making it easy to hold the rotor stationary during transport. This is not the case with the DC motors.

You will not find a thin plastic bag surrounding the rotor and covered by the chrome housing. This is done to prevent the rotor from moving during transport and thus prevent bearing damage due to unwanted rotor excursion.

Please **CAREFULLY** remove the cover and plastic bag and reinstall the chrome cover using the 3 small screws taped to the bottom of the cover. Make sure to align the notch in the cover with the cable leading to the motor. We recommend that you do this over a work bench to avoid dropping or mishandling the motor.

Please call customer service at 1-856-467-8000 if you have any questions.



601 Heron Drive
Logan Township, NJ 08085
Phone: 856-467-8000 • Fax: 856-467-3044
<http://www.radiosystems.com>